


#20-1 PIVOT DOOR

ASSEMBLY AND INSTALLATION INSTRUCTIONS

Unit should consist of one glass door panel, pivot jamb, one strike jamb, one drip channel, one piece of drip vinyl, one piece of pivot jamb vinyl, one bag of hardware.

- Step #1 Insert pivot jamb vinyl in the screw boss as drawing indicates and attach pivot plate to the bottom of pivot wall jamb.
- Step #2 Set pivot jamb to wall in "plumb" position marking one side and installation holes on pivot jamb. Note: Door must swing out.
- Step #3 Remove pivot jamb from wall and drill holes with $\frac{1}{4}$ " masonry drill bit if plastic plugs are needed. Insert plastic plugs to accept wood screws. (Plastic plugs to be purchased locally.)
- Step #4 Set pivot jamb back into opening and attach with wood screws provided. (#8 X 2" T.H. Phillips)
- Step #5 Measure from the center of the hole on pivot plate to opposite wall. This measurement ($-\frac{3}{8}$ ") will be distance you will need to set the top and bottom pivot pin from the outside edge of the strike rail of the door.
- Step #6 Set bottom of the door into the pivot plate. Then put the top pivot plate on and screw the plate to top of jamb.
- Step #7 Close door to a straight across position and set strike jamb between the end of door and against the wall with the strike leg of strike jamb against the door molding. These should be at least $\frac{1}{16}$ " to $\frac{3}{16}$ " space between door edge and strike jamb for closing clearance. Mark jamb location on the side and open door so that the location of the strike jamb holes can be marked for drilling. Drill holes and attach with screws provided. (#10 X 2" F.H. Phillips)
- Step #8 Cut drip channel $\frac{1}{4}$ " less than top and bottom of door. Cut drip vinyl same length as drip channel.
- Step #9 Attach drip channel to bottom of door with screws provided, but do not secure tight. Slip the drip vinyl between drip channel and door bottom molding and secure tight. Note: Drip vinyl must sweep the curb for a proper seal. Insert vinyl plug into drip channel at the strike jamb side.
- Step #10 Attach handles  from inside of door with screws provided and adjust. Wipe down with soft cloth.

